



Snom 720/D725 Instructions

1. Making Calls


i. Outside Calls




ii. Calling Other Extension



iii. Redial




2. Answering Calls




3. Transferring a Call / Call Transfer

i. Blind / Unattended Transfer



ii. Supervised / Attended Transfer



▶ Optionally, you can Talk and Inform about the call you are transferring  ▶




4. Holding a Call

i. To Hold



ii. To Retrieve a call (Call Hold retrieve)



5. **Holding in a System Parking Zone (Call Park)**

i. **To Hold**

During a conversation  Transfer to Park Extension (e.g. 400)

ii. **To Retrieve a call (Call Park retrieve)**

Press **Park 1**  (Light On)
Or
Press **Park 2**  (Light On)

6. **Making a conference (Conference Call)**

i. **To Establish a Conference**

During a conversation  Press  **Line 2**  Dial to 3rd Party  Press **Cnf.On**  Talk 

ii. **To Leave a conference and talk to the original person**

During a conference  Press  **Hold**  Press  **Line 2**  Press   Press  **Line 1**  Talk 


iii. **To Leave a conference and talk to the 3rd person**

During a conference  Press  **Hold**  Press  **Line 1**  Press   Press  **Line 2**  Talk 


iv. **To Leave a conference**

During a conference  Press 


7. Checking Voice Mail



8. Voice Mail Setup




9. Checking Call History




10. Forward Call


i. To set up All Call Forward Mode




ii. To set up Busy Call Forward Mode



iii. To set up Time / No Answer Call Forward Mode



iv. To Cancel Call Forward



11. Address Book

