



Snom D140 / D150 / D713 / D717 / D735 / D785 Instructions

1. Making Calls


i. Outside Calls




ii. Calling Other Extension



iii. Redial



2. Answering Calls





3. Transferring a Call / Call Transfer

i. Blind / Unattended Transfer



ii. Supervised / Attended Transfer




4. Holding a Call

i. To Hold




ii. To Retrieve a call (Call Hold retrieve)




5. Making a conference (Conference Call)

i. To Establish a Conference



Line 2
To Leave a conference and talk to the original person



ii. To Leave a conference and talk to the 3rd person

Line 2

Line 1




iii. To Leave a conference

Line 1


Line 2





6. Checking Voice Mail




7. Voice Mail Setup



8. DND (Do-Not-Disturb) Mode

- Enable DND – All incoming calls will be rejected
Press  once (DND icon will be displayed before the extension name)
- Disable DND
Press  once during DND mode


9. Checking Call History




10. Forward Call

i. To set up All Call Forward Mode


a) Method 1:




b) Method 2:



ii. To set up Busy Call Forward Mode




iii. To set up Time / No Answer Call Forward Mode



iv. To Cancel Call Forward

a) Method 1 (Applies to any call forward mode):



b) Method 2 (Applies to All Call Forward mode only):



11. Address Book

