



Cisco SPA30X/SPA50XG/SPA514G Instructions

1. Making Calls


i. Outside Calls



ii. Calling Other Extension



2. Answering Calls




3. **Transferring a Call / Call Transfer**

i. **Blind / Unattended Transfer**



ii. **Supervised / Attended Transfer**




4. **Holding a Call**

i. **To Hold**




ii. **To Retrieve a call (Call Hold retrieve)**



5. **Making a conference (Conference Call)**

i. **To Establish a Conference**



ii. **To Leave a conference and talk to the 1st person**



iii. **To Leave a conference and talk to the 3rd person**




iv. **To Leave a conference**




6. **Checking Voice Mail**

Press  ▶ Enter Password (if any)



7. **Voice Mail Setup**

Press  ▶ Enter Password (if any)



8. **Checking Call History**


i. To check the Dialed Calls

Press **redial**


ii. To check the Answered Calls



iii. To check the Missed Calls



9. Forward Call

i. To set up Always Call Forward

Press **cfwd**  Enter the target number (e.g. 108)


ii. To set up Busy Call Forward

Press   Choose "Call Forward"  Press **select**  Choose "CFWD Busy Number"

 Press **edit**  Enter the target number (e.g. 108)  Press **ok**  Press **save**
  

iii. To set up No Answer Call Forward

Press   Choose "Call Forward"  Press **select**  Choose "CFWD No Ans Number"

 Press **edit**  Enter the target number (e.g. 108)  Press **ok**  Press **save**
  

iv. To Cancel Call Forwarding

Press   Choose "Call Forward"  Press **select**  Choose the appropriate Call Forward mode

 Press **edit**  Press **clear**  Press   Press **ok**  Press **save**
   